Set Up Instructions

INFLATABLE TENT

Step 1: Take the tent out of the box. **CAUTION: To avoid any damages** or punctures to the frame, do not drag the tent frame around on the ground.



Step 5: Align and slide the nozzle onto the air pump hose. Twist to lock into place.





Step 3: Find the zipper head on the tent and attach the graphic to the frame.



Step 7: Around 90% of air fill lift top upward to pop canopy into place. Complete filling frame to 100%.



Step 4: Completely zip the graphic onto the frame.





Insert on one end to inflate tent. remove hose and place into other end to deflate tent.

Step 6: Turn the pump on and place

the nozzle over the air valve until

the valve and begins to inflate the

it completely drops downs over

frame.

