




NOTE: The extension poles are used for 1824 Curved frames






Aug 2018








Turn clockwise to lock foot in position
Turn anti-clockwise to unlock foot


NOTE: TWO POSITIONS FOR THE FEET (SEE OPTION 1 FOR SECOND POSITION)








NOTE: Adjustable feet can be used to level frame





Aug 2018



